



STEP 1) MARK CENTER LINE ON $\frac{1}{4}$ "
MDF BOARD – 7.75" WILL BE
CENTER OF BOARD



STEP 2.) MARK CENTER LINE OF
CABINET OPENING – SHOULD BE
7.5" ONLY WORKS FOR 15"
OPENING.



STEP 3.) LINE UP CENTER LINE FOR CABINET
OPENING AND 1/4" BOARD CENTER LINE



STEP 4) FASTEN rear center location with 3/4" deep
thread screw to hold when fastening the slides.



Line up slides with predrilled hold locations – always utilize front mounting location first & the rear of slide will align.