

Please find the recommended alternatives to the Famowood Solvent Thinner below:

Lacquer Thinner- 80/20 mix (80% lacquer thinner & 20% acetone)- Will not cause the material to cure too quickly and most consumers already have it on-hand.

1. MEK or Toluene – These products will not evaporate as quickly as Acetone.
2. Acetone – Acetone is normally available for purchase almost anywhere and a lot of consumers have it on-hand already. However, it will cause the material to cure very quickly.
3. Mineral Spirits – Will cause material to take longer to dry.
4. Paint Thinner – The composition varies depending on manufacturer. Test it on a small portion before thinning the entire can. It will most likely cause the putty to take longer to dry.

There may be certain regions where solvents such as lacquer thinner, MEK and Toluene are not available. In this situation, we recommend mineral spirits.

Please let me know if there is anything else I can assist with and have a great weekend!

Thank you,



Jodi McNeil
Customer Service Rep
Eclectic Products LLC
Eugene, OR
800-349-4667 x1126 Office
eclecticproducts.com