



# Industrial Downdraft Table

## Operating Manual

### Models:

**64492** - 91 cm x 183 cm (36 in. x 72 in.)




Model: 64492 Shown

**Keep workplace area free of contaminants while sanding and finishing wood or non-combustible materials.**

**Keep machine running when not in use to help clean the shop environment.**



## SAFETY LEGEND



### ⚠ WARNING

Read and understand tool manual before work starts to reduce risk of injury to operator, visitors, and tool.

### ⚠ WARNING

Practice safety requirements. Work alert, have proper attire, and do not operate tools under the influence of alcohol or drugs.



### ⚠ WARNING

Eye protection must be worn at all times, eye protection to conform to ANSI Z87.1.

### ⚠ WARNING

Ear protection to be worn when exposure to sound, exceeds the limits of applicable Federal, State or local statutes, ordinances and/or regulations.



### ⚠ WARNING

Respiratory protection to be used when exposed to contaminants that exceed the applicable threshold limit values required by law.

### ⚠ WARNING

Electric shock hazard. Avoid bodily contact with grounded objects, bodies of water. Do not damage cord set.



## IMPORTANT SAFETY INSTRUCTIONS

**When operating this equipment, basic precautions should always be strictly followed including the instructions listed below:**

### DOWNDRAFT TABLE SAFETY INSTRUCTIONS

1. Always use a grounded power supply. There is an increased risk of electric shock with an ungrounded power supply.
2. Don't expose to rain or wet conditions. There is an increased risk of electric shock if the switch, cord or motor are wet.
3. Do not abuse the power cord. Never use the cord to move the table. Never use the cord to pull the plug from an outlet. A damaged cord increases the risk of electric shock.
4. Use caution when opening or closing the top. Switch power off and unplug cord before opening top. Remove all work pieces and


tools before opening top to avoid injury. Keep fingers and hands clear when closing the top to avoid injury.

5. Never use to exhaust chemical vapors
6. Vibration may occur if unit is unlevel.
7. Unplug power cord when accessing blower compartment area.
8. Power switch must be off when servicing filter.
9. Do not use this table to sand or grind materials that may create sparks.
10. Do not use for explosive metallic dust (Aluminum, Magnesium, etc.)

### IMPORTANT NOTICE

# COMPLETE ASSEMBLY DIAGRAM

See page 3 for Label Identification



## REPLACEMENT PARTS

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	64251	Downdraft Table Top	1
2	64986	Pre-Filter	1
3	64671	Air Filter	3
4	64214	Sheave	1
5	64215	V-Belt	1
6	64213	Sheave	1
7	98609	Terminal	13
8	98422	230V Label	1
9	98420	Arrow Label	1
10	98615	Wire Connector	1
11	98365	1hp Motor	1
12	64211	Blower	1
13	64239	Hex Nut (Nylon Insert)	4
14	95183	Washer	4
15	64232	Bolt	20
16	98746	Lock Nut	1
17	98701	Cord Grip	3
18	98751	Seal Ring	1
19	64233	Cord	1
20	64230	Screw	28
21	64225	Bracket	2
22	64222	Gas Shock/Spring	2
23	64223	Ball Socket	4
24	64224	Bracket	2
25	64220	Hinge	1
26	64226	T-Nut	28
27	64234	Screw	46
28	65059	Name Plate	1
29	64257	Corner Guard	4
30	64218	Locking Caster	2
31	95042	Lock Washer	16
32	97216	Nut	16
33	64227	Wire Mesh	1
34	64258	Air Dam	1
35	64219	Rigid Caster	2
36	97546	Washer	10
37	97683	Switch	1
38	64216	Box	1
39	97498	Screw	2
40	97684	Switch Cover	2


## LABEL IDENTIFICATION

### REPLACEMENT FILTERS

Reorder No. 64671  
Standard Paper Air Filter  
Reorder No. 64672  
UL Rated Class I  
Non-Flammable Air Filter  
(Filters sold separately / 12 Filters per case)

Reorder No. 64985  
Pre-Filter (33x60)  
Reorder No. 64986  
Pre-Filter (36x72)

**Dynabrade Customer Service**  
Within USA Call (716) 631-0100 or 888-DYNABRADE  
[www.dynabrade.com](http://www.dynabrade.com)



**64679**  
Replacement Filter Label

**64696**  
Electric Warning Label

**64697**  
Spark Warning Label

**64698**  
Information Label

## SET-UP/OPERATING/MAINTENANCE INSTRUCTIONS

### DOWNDRAFT TABLE SET UP INSTRUCTIONS

1. Make sure power cord is unplugged from power supply.
2. Install two rigid casters and two swivel casters into position as shown on complete assembly diagram (pg. 2).
3. Remove cardboard strips from bottom of table to allow for air dam to function properly.
4. Position table in work area and lock swivel casters to stabilize the table.
5. Install provided filters and pre-filter.
6. Make sure top is closed and power switch is off before plugging cord into grounded power supply.

### DOWNDRAFT TABLE OPERATING AND MAINTENANCE INSTRUCTIONS

1. Switch power on to begin dust collection.
2. Do not block more than 50% of inlet holes during use.
3. Do not obstruct outlet.
4. Switch power off and unplug cord before opening top.
5. Clean pre-filter and pleated filters daily.
6. Clean top surface only with brush or dry cloth as necessary.
7. Do not use alcohol on top surface.
8. Replace filters every 30-60 days as necessary.
9. Vacuum filter support rails regularly to assure proper seating.

## MACHINE SPECIFICATIONS

Model Number	Motor W (hp)	Voltage	Phase	Vacuum Suction	Sound Level	Working Area Width	Working Area Length	Height cm (Inch)	Shipping Wt. kg (lbs.)
64492	550 (.75)	230/50Hz	1	1900 SCFM	72 dB(A)	91 cm (36")	183 cm (72")	91 (36)	166 (365)

## OPTIONAL ACCESSORIES

### REPLACEMENT FILTERS

- 64671** Standard Paper Air Filter  
**64672** UL Rated Class I Non-Flammable Air Filter

### REPLACEMENT GRIP TOP

- 64253** For use with Model: 64492

### REPLACEMENT PRE-FILTERS

- 64986** 36 in. x 72 in.

Note: Filters sold separately / 12 Filters per case

## DYNABRADE CUSTOMER SERVICE

**US Consumers Call Toll-Free: 1-800-828-7333 • Canadian Consumers Call Toll-Free: 1-800-344-1488**

#### **DYNABRADE, INC.**

8989 Sheridan Drive • Clarence, New York 14031-1490 • Phone: (716) 631-0100  
Fax: 716-631-2073 • US Consumers Call Toll Free: 1-800-828-7333

#### **DYNABRADE INTERNATIONAL**

8989 Sheridan Drive • Clarence, New York 14031-1490 • Phone: (716) 631-0100  
Fax: 716-631-2524 • Canadian Consumers Call Toll Free: 1-800-344-1488

#### **DYNABRADE EUROPE S.à r.l.**

Zone Artisanale • L-5485 Wormeldange-Haut, Luxembourg  
Phone: +352 768 494 1 • Fax: +352 768 495

#### **DYNABRADE DO BRASIL**

Rua Mário Fongaro • 421 – Vila Marlene • São Bernardo do Campo  
SP – CEP 09732-530 • Telefax: (11) 4124-6040

[www.dynabrade.com](http://www.dynabrade.com)

