

STEP-1. SCREW CH11 BRACKET TOGETHER

STEP-2. CHOOSE FROM DRY WALL ANCHORS OR
CONCRETE ANCHORS FOR WALL

STEP-3

ASSEMBLY NEEDED FOR CONCRETE ANCHORS

DRILL TWO 5/16" DIA HOLE X 1-1/8" O.C. VERTICAL

STEP-4


INSERT BOTH ANCHORS, YOU MAY WANT TO USE
A RUBBER Mallet.

INSERT SUPPORT PIECE AND SCREWS

TIGHTEN THE SCREWS EVENLY UNTIL IT HAS A GOOD HOLD

STEP-5

INSTALL SH11 BY SLIDING FROM THE TOP



STEP 6
USE LEVELER TO ADJUST WALL TO BE EVENLY

NOTE:

WEIGHT CAPACITY

CONCRETE: 80 LBS. PER BRACKET

INTO STUDS: 80 LBS. PER BRACKET

DRY WALL: 25 LBS. PER BRACKET

MOUNT BRACKETS NO MORE THAN 36" APART

+/- 1/16" OVER ALL TOLERANCE

DRY WALL ANCHOR

STEP-2




CONCRETE ANCHOR




STEP-3


1-1/8" O.C.




DRY WALL
STEP-4



CONCRETE ANCHOR
STEP-4



STEP-5



STEP-6

