



Product Data Sheet

Product Number: F-200 / F-200G / F-200R
Description: Canister Contact Adhesive, Spray Grade

Typical Physical Properties

Adhesive:	Flam/Non-Flam (Propellant/Adhesive)	Pattern:	Web
Dry Time:	2 - 3 Minutes	Solvents:	Methylene Chloride, Propane
Open Time:	30 Minutes	Flash Point:	-156° F
Color:	Clear / Green / Red	VOC:	426 g/l (EPA Method 24)
Coverage Rate:	2.5 Dry Grams/Sq Ft Minimum	Clean Up	Choice 689 or Citrus Cleaner
Shelf Life:	1 Year In Unopened Container	Class:	Extremely Flammable
Packaging:	16 oz (Clear), 11, 38, 177 & 355 lb Canisters		
Shipping:	Liquefied Gas, Flammable, 2.1, UN3161		

Qualifies for LEED®-NC & CI EQ Credit 4.4: laminating adhesives shall contain no urea formaldehyde resins

Properties:

- High Bond Strength
- High temperature flammable canister contact cement
- Excellent adhesion to a variety of substrates including, but not limited to laminates, particle board, plywood, hardwood, leather rubber and metal.
- Fast drying
- Excellent room temperature contactability
- High heat resistance
- Portable System

Application:

1. Prepare the surface to be bonded. Ensure both faces are clean and free of dust, dirt and grease. If necessary, wipe clean with CBA Citrus Cleaner.
2. Hold spray gun at a constant distance of between 6-10 inches (150-250mm) from the surface, allowing adhesive to cobweb across the surface with minimal overlap for thick laminates. For thin laminates allow for approximately 50% overlap of successive passes to prevent telegraphing.
3. Maintain a constant hand speed during spraying. Apply a consistent and thorough coating without allowing the adhesive to puddle or heavily wet the surface. Maximum bond strength is achieved with substrate coverage between 80-100% with a recommended coat weight minimum of 2.5 dry grams per square foot.
4. Maximum adhesion will be obtained by spraying opposing mating faces with an adhesive pattern at 90° angles to each other. (Example: Face one substrate vertically while spraying. Face the other substrate horizontally. Extra coverage is recommended at substrate edges.
5. Hold spray gun at 90° angle to substrate surface while spraying. Release trigger at end of each pass to optimize coverage.

FORMICA is a registered trademark of the Formica Corporation

NOTICE TO PURCHASER: The information, data and suggestions for use of the materials given here are based on our best experience and knowledge, but we do not guarantee the results to be obtained in customer's processes. The products discussed are sold without any warranty regarding merchantability or fitness for a particular purpose or any other warranty express or implied. Before using, user shall determine the suitability of the product for his intended use, and user assumes all risk and liability whatsoever in connection therewith. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Sellers and manufacturers only obligation shall be to replace such quantity of the product proved to be defective. Since the manufacturer of the described in this data sheet has no means of controlling the final use of the product by the consumer or user, it is the responsibility of the immediate purchaser and any intermediate sellers to inform the user of the purposes for which the product may be fit and suitable, and of the properties of the product, including the precautionary measures which must be taken in order to insure the safety of the user and of other third persons and property.



666 Redna Terrace, Suite 600
Cincinnati, OH 45215
Customer Service: (800) 330-5566

6. Allow adhesive to dry completely before attempting assembly. (Dry time may vary due to humidity and temperature variations.) Test for dryness using back of hand only – surface should be tacky, but adhesive should not transfer to the skin.
7. Position substrates carefully and apply pressure. Work from the center of the substrate, out to prevent bubbles and wrinkles. Apply adequate pressure (40 PLI) using nip roller. Proper use of a 3” J-roller will also provide proper pressure.
8. The bonded assembly is immediately able to be trimmed or routed. Full bond strength is achieved after 24-48 hours depending on temperature and humidity.

Handling and Application:

Attach and securely tighten a hose, in your length of choice to the matching fitting provided on the gun. Attach the other end of the hose to the matching fitting on the canister. It is recommended that plumbers tape be used on the fittings to assure an air tight seal. Check the fittings again for tightness. Slowly open the valve on the top of the canister and check for leaks. Half way is recommended at first. When hose is connected, keep canister valve open and hose pressurized at all times. Do not disconnect the hose until ready connect to new canister. Release pressure in hose before disconnecting from canister. Do not use in applications with copper or aluminum components. This adhesive is not recommended for use with plasticized vinyl, flexible plastics, expanded/extruded polystyrene, polyethylene, or polypropylene. Use only in well ventilated areas. Do not use near ignition sources.

Storage Conditions:

Store between 60° F and 90° F for best performance. Do not expose to direct sunlight. Diminished performance may occur below 60° F. If so, warm canister to room temperature. Remove directly from concrete floor in cold temps. Do not freeze.

Attention: Empty container remains hazardous until all flammable vapors, which may explode upon ignition, are gone from residue and container. Observe all labeled hazard precautions. Do not cut, puncture, or weld while hazard exists. Do not reuse empty container. Recycle, or dispose of, according to all federal, state, and local regulations.

Use in conjunction with: Adjustable Spray Gun (part no LJC6106) w/ 6501 Tip and hose

Please refer to the Material Safety Data sheet for further information.